

FIRE RATED: CLASS 0 ('Class 0' is the ultimate wallpaper classification for reaction to fire)

HELPS PROTECT FLAMMABLE SURFACES IN THE EVENT OF FIRE

VERY STRONG, REINFORCED LINING FOR COVERING SURFACES QUICKLY & EASILY

PASTE THE WALL OR THE PAPER

RECOMMEND PASTE: WALLROCK READY-MIXED ADHESIVE

Covers damaged

walls and ceilings

Retford Wallcoverings Ltd, Gainsborough, DN21 1QB, UK

Helpline: +44 (0)1427 616597

www.anaglypta.co.uk

www.erfurtmav.com



Cladding

Improves and reinforces on:

Cracked Ceilings

Damaged & Crumbling Plaster

Red Label Insulation Products



Wallrock Thermal Insulation Products

SINGLE 54.5cm(21") roll









Recommended adhesive and consumption Wallrock Adhesive, 0.2Kg - 0.4Kg per m24







Wallrock FireLiner is the modern alternative to traditional lining papers, producing a superb finish both quickly and easily which is also highly durable and fire resitant

Wallrock FireLiner produces a very strong base on problem surfaces that cannot be covered by conventional wall coverings, and is also particularly good for covering plaster, plasterboard, insulating wallpapers and thermal boards without having to apply a plaster skim. Once dry, it can be emulsion painted or overhuna with another wallcoverino.

It is important that all surfaces are free from dust and loose particles. Fill and smooth large cracks or holes, Wallrock will bridge any small crack and holes. If the surface is porous eg. plasterboard and old plaster, seal with a size designed for the purpose. For wood panelling, rub down with sandapaor to form a ker for the adhesive.

Excessively porous surfaces should be sized with a suitable PVA based bonding solution, whilst smooth impervious surfaces should be roughened slightly.

Use a ready-mixed adhesive. We recommend **Wallrock Power Adhesive** for perfect results, or any good quality heavy duty wallpaper paste. If in doubt, itsel-hang a piece or consult your decorating relatine. Before hanging, check all rolls are the same product and undamaged, and that you have enough for the job in hand. Return any faulty or damaged rolls with their label(s) from where purchase).

WARNING: Turn off electricity supply before working around plug points, light fittings and switches.

Retford Wallcoverings Ltd will not be held liable for any badly hung or faulty material after hanging, nor for poor results due to ill-prepared surfaces. Follow all instructions carefully including those of paste and paint products used.

## Instructions for hanging Wallrock FireLiner

- Cut all lengths required allowing extra for trim at each end, or simply hang directly from the roll onto a prepasted wall or ceiling. Apply the inner surface to the wall. Please note Wallrock FireLiner can also be hung horizontally, especially useful if you intend to overhang with a decorative wallpaper.
- Mark a guideline with a pencil for the first length, using a plumbline as a guide for vertical drops or a spirit level for horizontal application.
- 3. If applying the adhesive direct to the wall or ceilings, apply enough to hang one or two lengths at a time, ensuring the paste exceeds the width of the second length. If pasting the material (either side) make sure all edges are covered. With both methods, hang Wallrock FireLiner immediately - no soaking is required.

- Apply the first length along the guideline and smooth out with a wallpaper brush then trim the ends.
- Butt join all subsequent lengths being careful not to overlap the edges.
- Allow Wallrock to dry thoroughly before decorating with emulsion paint or overhanging with another wallcovering (normally 24 hours is sufficient).

Wallrock FireLiner is also 'dry strippable' in many applications.













www.anaglypta.co.uk www.erfurtmav.com Retford Wallcoverings Ltd, Gainsborough, DN21 1QB, UK Helpline (UK): +44 (0)1427 616597

<sup>\*</sup> Please note the Class O fire certification was achieved using Wallrock adhesive.



('Class 0' is the ultimate wallpaper classification for reaction to fire)

HELPS PROTECT FLAMMABLE SURFACES IN THE EVENT OF FIRE

VERY STRONG, REINFORCED LINING FOR COVERING SURFACES QUICKLY & EASILY

PASTE THE WALL OR THE PAPER

RECOMMEND PASTE: WALLROCK READY-MIXED ADHESIVE

Covers damaged

walls and ceilings

Retford Wallcoverings Ltd, Gainsborough, DN21 1QB, UK

Helpline: +44 (0)1427 616597

www.anaglypta.co.uk

www.erfurtmav.com



Cladding

Improves and reinforces on:

Cracked Ceilings

Damaged & Crumbling Plaster

Red Label Insulation Products



Wallrock Thermal Insulation Products

DOUBLE 54.5cm(21") roll









Recommended adhesive and consumption Wallrock Adhesive, 0.2Kg - 0.4Kg per m24







Wallrock FireLiner is the modern alternative to traditional lining papers, producing a superb finish both quickly and easily which is also highly durable and fire resitant

Wallrock FireLiner produces a very strong base on problem surfaces that cannot be covered by conventional wall coverings, and is also particularly good for covering plaster, plasterboard, insulating wallpapers and thermal boards without having to apply a plaster skim. Once dry, it can be emulsion painted or overhuna with another wallcoverino.

It is important that all surfaces are free from dust and loose particles. Fill and smooth large cracks or holes, Wallrock will bridge any small crack and holes. If the surface is porous eg. plasterboard and old plaster, seal with a size designed for the purpose. For wood panelling, rub down with sandapaor to form a ker for the adhesive.

Excessively porous surfaces should be sized with a suitable PVA based bonding solution, whilst smooth impervious surfaces should be roughened slightly.

Use a ready-mixed adhesive. We recommend **Wallrock Power Adhesive** for perfect results, or any good quality heavy duty wallpaper paste. If in doubt, itsel-hang a piece or consult your decorating relatine. Before hanging, check all rolls are the same product and undamaged, and that you have enough for the job in hand. Return any faulty or damaged rolls with their label(s) from where purchase).

WARNING: Turn off electricity supply before working around plug points, light fittings and switches.

Retford Wallcoverings Ltd will not be held liable for any badly hung or faulty material after hanging, nor for poor results due to ill-prepared surfaces. Follow all instructions carefully including those of paste and paint products used.

## Instructions for hanging Wallrock FireLiner

- Cut all lengths required allowing extra for trim at each end, or simply hang directly from the roll onto a prepasted wall or ceiling. Apply the inner surface to the wall. Please note Wallrock FireLiner can also be hung horizontally, especially useful if you intend to overhang with a decorative wallpaper.
- Mark a guideline with a pencil for the first length, using a plumbline as a guide for vertical drops or a spirit level for horizontal application.
- 3. If applying the adhesive direct to the wall or ceilings, apply enough to hang one or two lengths at a time, ensuring the paste exceeds the width of the second length. If pasting the material (either side) make sure all edges are covered. With both methods, hang Wallrock FireLiner immediately - no soaking is required.

- Apply the first length along the guideline and smooth out with a wallpaper brush then trim the ends.
- Butt join all subsequent lengths being careful not to overlap the edges.
- Allow Wallrock to dry thoroughly before decorating with emulsion paint or overhanging with another wallcovering (normally 24 hours is sufficient).

Wallrock FireLiner is also 'dry strippable' in many applications.













www.anaglypta.co.uk www.erfurtmav.com Retford Wallcoverings Ltd, Gainsborough, DN21 1QB, UK Helpline (UK): +44 (0)1427 616597

<sup>\*</sup> Please note the Class O fire certification was achieved using Wallrock adhesive.